USB
SD
1
2
3
PROG
4
5
6
REP
7
8
9
A>B
FOLDER
0
RAN
PLAY
II

ROLLS
www.rolls.com
HR74
MP3 Player
SD CARD & USB
POWER
001
FOLDER
SD CARD
PREV
NEXT
STOP
PLAY
PAUSE II
IR
RAN
REPEAT
A→B
USB
OUTPUTS
STEREO
3.5MM
9-15
VDC
ROLLS
www.rolls.com
HR74
MP3 CARD READER