HR260 RACK INSTRUCTIONS





- 1 HR260 rack
- 4 Small flat head screws 4/40
- 4 Large flat head screws 6/32

The HR260 rack tray is designed to securely hold Rolls products so they can be mounted in a single half rack space. The HR260 is designed to house the HR72, HR73, HR74, HR78, MX153 or HR155. It can potentially hold other products but you will need to drill mounting holes in the HR260 or the product you intend to mount in the HR260.

To mount the HR72, HR73, HR74 or HR78. You will need to remove the bump-on's (bottom rubber feet) from the unit being mounted. Pull out the side screws in the unit being mounted (2 Large flat head screws per side). Then use the large flat head screws to attach the units to the HR260 from the side. Use the small flat head screws to attach the unit to the HR260. NOTE: YOU ARE ATTACHING A METAL RACK TRAY TO PLASTIC FRONT PANELS. DO NOT OVER TIGHTEN THE SCREWS AS THEY WILL EASILY BREAK THE PLASTIC FRONT OF THE UNIT.

To attach a MX153 or HR155 to the HR260. First remove any bump-on's (bottom rubber feet) from the unit being mounted. Attach the large flat head screws through the bottom of the HR260, line them up with the holes on the bottom of the unit being attached.

